

Dodge Factory Harness Adapter #57300

Make / Model	Style	Years
Chrysler		
Aspen	with Factory Tow Package	2007-2009
Dodge		
Dakota	with Factory Tow Package	2000-2009
Durango	with Factory Tow Package	2000-2008
Ram 1500	with Factory Tow Package	2000-2008
Ram 1500 Van	with Factory Tow Package	2001-2003
Ram 2500	with Factory Tow Package	2000-2009
Ram 2500 Van	with Factory Tow Package	2001-2003
Ram 3500	with Factory Tow Package	2000-2009
Ram 3500 Van	with Factory Tow Package	2001-2003
Sprinter 2500	with Factory Tow Package	2003-2009
Sprinter 3500	with Factory Tow Package	2003-2009
Freightliner		
Sprinter 2500	with Factory Tow Package	2003-2009
Sprinter 3500	with Factory Tow Package	2003-2009
Jeep		
Commander	with Factory Tow Package	2006-2010
Grand Cherokee	with Factory Tow Package	2000-2010
Liberty	with Factory Tow Package	2005-2008
Mitsubishi		
Raider	with Factory Tow Package	2006-2009